



STEP 1

LOCATE THE 13 ½ INCH METAL ROD AND HOLD SO THE THREADED PORTION FACES DOWN.

STEP 2

LOCATE THE 5 INCH METAL PLATTER HOLDER AND ATTACH TO PIECE IN STEP 1 BY SLIDING THE 13 ½ INCH ROD THROUGH THE HOLE OF THE METAL PLATTER HOLDER. THE CAP ON THE METAL PLATTER HOLDER SHOULD BE AT THE BOTTOM.

STEP 3

LOCATE THE OTHER 5 INCH METAL PLATTER HOLDER AND REPEAT STEP TWO.

STEP 4

LOCATE THE REMAINING 2 ½ INCH METAL PLATTER HOLDER AND REPEAT STEP TWO.

STEP 5

ONCE ALL THREE METAL PLATTER HOLDERS ARE SECURED BY THE 13 ½ INCH METAL ROD, SCREW THE ROD INTO THE METAL BASE. POSITION THE RINGS AS YOU WISH AND CONFIRM CENTER POLE IS TIGHTLY SECURED. ONCE SECURE, THE GLASS PLATTERS CAN BE ADDED.

NOTE

THE SHORT ½ INCH END ATTACHING THE RING SHOULD BE UP.

NOTE

IF STAND WOBBLER EXCESSIVELY, CENTER POLE NEEDS TO BE TIGHTER.